

GO ezFILL Pump Instructions

For use with HP 5500/5000



- System is Easy to Use
- System Pays for Itself After the First Use
- Electronic Chip Handles the Ink Cassettes
- Ink System for 6 Colors Including Tubes and Containers

Product Summary

Many users of the HP 5500/5000 have been impressed with the overall performance of the HP 5500/5000. One of the concerns expressed by users is the high cost of replacing the cartridges and the ink. Graphics One now has a solution to address this concern: the GO ezFill PumpSystem with GO hInk.

The ezFill Pump System is ideal for the user who uses the HP 5000/5500 4-6 hours a day. The ezFill Pump System is an easy to use pumping system that allows the user to refill the cartridge with a simple press of the pump. Two hoses attach into the back of the cartridge and within minutes, the cartridge is refilled and ready for use.

GO ezFill Refilling Kit

The ezFill refill system contains 6 cassettes, 6 liters of ink (1 liter each of color), a pump system, all appropriate hoses and an accessories package that compliments the refill system. The ezFill System also offers the GO ezFill Transmitter Chip for communicating ink data to the HP 5000/5500 and instructions for the system. GO recommends using GO's high quality hInk for refilling the ezFill Pump System for an additional cost saving strategy.

Installation Instructions:

- Step 1. Execute the "Replace Ink Cartridge" command and pull out the appropriate ink cartridge.
- Step 2. There are two tubes on the ink cartridge. The top tube next to the chip is the one you use for refilling. The tube on the bottom allows air to exit when you are refilling.
- Step 3. You can open the bottom tube by inserting a 2-3mm wide pin.
- Step 4. Insert the desired ink into the top tube using a size appropriate syringe.
- Step 5. Always refill the cartridge before the ink runs out.